

## CENO INSTALLATION INSTRUCTIONS | JUNE 2020



rotation angle

installation for 1.0





Driver must be powered off before connecting cables.


Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.






1.0 LED











## MOUNTING INSTRUCTION

- Make a hole in the ceiling according to the prescribed dimensions.
- 2 POWER CONNECTION


**LED** Always use a driver according to the specifications of the LED module.

## Single connection





## Multiple connection



**3** Push the springs up and insert the fixture in the ceiling hole.

tilt angle