







CENO SURFACE

INSTALLATION INSTRUCTIONS | AUGUST 2022

Installation for 1.0 / 2.0 / 4.0 / 4.1




Mounting base:




Only to be installed outside arms reach.


DIMENSIONS




1.0 LED



2.0 LED



4.0 LED




4.1 LED


MOUNTING INSTRUCTION

1 Remove the mounting base from the luminaire by loosening the socket screws and mount it on the ceiling with screws (screws are not included).

2 POWER CONNECTION
Connect to 220-240V.



Connect the ceiling base earth cable.



3 Attach the luminaire to the mounting base with the screw opposite side first and tilt towards the ceiling as shown.

4 Fix the luminaire on the base with the socket screws.



WEVER & DUCRÉ
LIGHTING


WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com

PB19-010-677-00_V3

CENO SURFACE

INSTALLATION INSTRUCTIONS | AUGUST 2022

Dismounting for 1.0 / 2.0 / 4.0 / 4.1



DISMOUNTING INSTRUCTION

Light source & driver

- 1** Loosen the socket screws from the fixture to remove it from the mounting base.
- 2** Disconnect the wires to remove the driver(s).
- 3** Pull out the snoot and lens.
- 4** Unscrew the screws and remove the light source.



The light source is replaceable by an authorized professional.
For advice contact your Wever & Ducré customer service contact point.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class E.